SAMSUNG

DIGITAL HOME THEATER SYSTEM

HT-DM150

Instruction Manual



DOLBY DIGITAL PRO LOGIC II
DIGITAL dts SURROUND
DVD VIDEO
COMPACT disc DIGITAL AUDIO
COMPACT disc DIGITAL VIDEO
MP3 DIGITAL DISC PLAYBACK

Safety Warnings

CLASS 1 LASER PRODUCT
KLASSE 1 LASER PRODUKT
LUOKAN 1 LASER LAITE
KLASS 1 LASER APPARAT
PRODUCTO LASER CLASE 1


CAUTION
RISK OF ELECTRIC SHOCK.
DO NOT OPEN
CAUTION:
TO REDUCE THE RISK OF ELECTRIC SHOCK, DO NOT REMOVE REAR COVER. NO USER SERVICEABLE PARTS INSIDE. REFER SERVICING TO QUALIFIED SERVICE PERSONNEL.

CLASS 1 LASER PRODUCT

This Compact Disc player is classified as a CLASS 1 LASER product.

Use of controls, adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

CAUTION-INVISIBLE LASER RADIATION WHEN OPEN AND INTERLOCKS DEFEATED, AVOID EXPOSURE TO BEAM.

This symbol indicates that dangerous voltage which can cause electric shock is present inside this unit.

This symbol alerts you to important operating and maintenance instructions accompanying the unit.

WARNING: To reduce the risk of fire or electric shock, do not expose this appliance to rain or moisture.

CAUTION: TO PREVENT ELECTRIC SHOCK, MATCH WIDE BLADE OF PLUG TO WIDE SLOT, FULLY INSERT.

Precautions





Ensure that the AC power supply in your house complies with the identification sticker located on the back of your player. Install your player horizontally, on a suitable base (furniture), with enough space around it for ventilation (3~4inches). Make sure the ventilation slots are not covered. Do not stack anything on top of the player. Do not place the player on amplifiers or other equipment which may become hot. Before moving the player, ensure the disc tray is empty. This player is designed for continuous use. Switching off the DVD player to the stand-by mode does not disconnect the electrical supply. In order to disconnect the player completely from the power supply, remove the main plug from the wall outlet, especially when left unused for a long period of time.



During thunderstorms, disconnect the main plug from the socket.
Main voltage peaks due to lightning could damage the unit.



Do not expose the unit to direct sun radiation or other heat sources.
This could lead to overheating and malfunction of the unit.



Protect the player from moisture(dripping or splashing and that no objects filled with liquids,such as vases, shall be placed on the player), and excess heat(e.g.fireplace) or equipment creating strong magnetic or electric fields (i.e.speakers...) disconnect the power cable from the mains electricity supply if the player malfunction. Your player is not intended for industrial use but for domestic purposes only. Use of this product is for personal use only. Condensation If your player or disc have been stored in a cold atmosphsre. as for example during transportation in the winter, wait for approximately 2 hours until they have reached room temperature.



The battery used in this product contains the chemicals that are harmful to the environment.
Do not dispose of batteries in the general household waster. It is recommended that the replacement of the battery should be done by technician.

DVD (Digital Versatile Disc) offers fantastic audio and video, thanks to Dolby Digital surround sound and MPEG-2 video compression technology. Now you can enjoy these realistic effects in the home, as if you were in a movie theater or concert hall.

DVD players and the discs are coded by region. These regional codes must match in order for the disc to play. If the codes do not match, the disc will not play.
The Region Number for this player is given on the rear panel of the player.
(Your DVD player will only play DVDs that are labeled with identical region codes.)

Do not use the following types of disc!

- LD, CD-G, CD-I, CD-ROM and DVD-ROM cannot be played on this player.
  If such discs are played, a "**WRONG DISC FORMAT**" message appears on the TV screen.
- DVD discs purchased abroad may not play on this player.
  If such discs are played, a "**WRONG REGION CODE**" message appears on the TV screen.

Copy Protection

- **Many DVD discs are encoded with copy protection. Because of this, you should only connect your DVD player directly to your TV, not to a VCR. Connecting to a VCR results in a distorted picture from copy-protected DVD discs.**
- This product incorporates copyright protection technology that is protected by methods claims of certain U.S. patents and other intellectual property rights owned by Macrovision Corporation and other rights owners. Use of this copyright protection technology must be authorized by Macrovision Corporation, and is intended for home and other limited viewing uses only unless otherwise authorized by Macrovision Corporation. Reverse engineering or disassembly is prohibited.

Contents

CHAPTER 1. PREPARATION

- Safety Warnings 1
- Precautions 2
- Description 5
- Remote Control 7
- Listening on headphones 8

CHAPTER 2. CONNECTIONS

- Connecting the Speakers 9
- Connect Video to TV 10
- Connecting the FM and AM(MW/LW) Antennas 11
- AUX Connections 12
- Controlling a TV with the Remote 13
- Connecting your System to the Power Supply 13
- Before Using the DVD Player 14

CHAPTER 3. OPERATION

- DVD Playback 15
- MP3-CD Playback 17
- Forward/Reverse Searching 19
- Slow Playback/Checking the Remaining Time 20
- Repeat Playback 21
- Using Disc Menu/Title 22
- Selecting the Audio Language/Subtitle Language 23
- Zoom/Angle Functions 24
- Program Playback 25
- Sleep/D.R.C Function 27

CHAPTER 4. SETUP

- Setting up the Language Features 28
- System Setup 29
- Speaker Setup 31
- To set up Speaker Balance 33
- Creating Realistic Sound Fields 34
- Dolby Pro Logic II decoder 35
- DSP (Digital Signal Processor) Modes 37
- To increase Effect level 38
- Adjusting DSP Sound Parameters 38

CHAPTER 5. RADIO OPERATION

- Listening to the Radio 39
- Presetting stations 40

CHAPTER 6. MISCELLANENOUS

- Troubleshooting 41
- Cautions on Handling and Storing Discs 43
- Disc Type and Protection 44
- Specifications 45
- Reference 46

Description

Front Panel



Display



Rear Panel

External Video Component Input Connector

External Digital Component Input Connectors
Use these for connections to external equipment capable of digital output.

Video Output Connector
Connect the TV's video input jacks (VIDEO IN) to the VIDEO OUT connector.

S-Video Output Connector
If the TV is equipped with an S-Video input connector (S-VIDEO IN), connect it to the player's S-Video output jack.

AM Antenna Connector



FM Antenna Connector

5.1 Channel Speaker Output Terminals

Voltage Selector(option)

External Audio Component Input Connector

COMPONENT VIDEO OUTPUT/INPUT jacks
Connect a TV with component video input jacks to these jacks.

Accessories

Remote Control


Video/Audio Cable


AM Antenna


FM Antenna

User's Manual

Remote Control Unit



Insert Remote Batteries



1 Remove the battery cover on the back of the remote by pressing down and sliding the cover in the direction of the arrow.

2 Insert two 1.5V AAA batteries, paying attention to the correct polarities (+ and –).

3 Replace the battery cover.

CAUTION

Follow these precautions to avoid leaking or cracking cells:

- Place batteries in the remote control so they match the polarity:(+) to (+)and (–)to (–).
- Use the correct type of batteries.Batteries that look similar may differ in voltage.
- Always replace both batteries at the same time.
- Do not expose batteries to heat or flame.

Range of Operation of the Remote Control

The remote control can be used up to approximately 23 feet/7 meters in a straight line. It can also be operated at a horizontal angle of up to 30° from the remote control sensor.



To open the remote control cover, push the top of the cover, then slide downward.



Listening on headphones

Listening on headphones

Use headphones (not supplied) for private listening pleasure.

Connect the headphones to the HEADPHONES jack of the front panel.

- No sound is produced from the speakers.
- To prevent hearing damage, do not raise the volume level excessively when using headphones.



Connecting the Speakers

- Connect the satellite speakers, center speaker, and subwoofer to the terminals on the rear panel using speaker cords supplied.
- Connect the red cord to the red (+) terminal and the black cord to the black (-) terminal.



1 **Press and hold the terminal tab.**

2 **Insert the speaker cord.**

3 **Release the finger.**





Note • For details on the "**Ideal Speaker Placement**" see page 32.

Connect Video to TV



* Depending on your TV, Component Video input connectors may be marked as DVD Video input connectors.

Composite Video (Good Quality)
Connect the supplied video cable from the VIDEO OUT jack on the back panel of the system to the VIDEO IN jack on your television.

S-Video (Better Quality)
If you television is equipped with an S-Video input, connect an S-Video cable (not supplied) from the S-VIDEO OUT jack on the back panel of the system to the S-VIDEO IN jack on your television.

Component Video (Best Quality)
If your television is equipped with Component Video inputs, connect a component video cable (not supplied) from the Pr, Pb and Y jacks on the back panel of the system to the corresponding jacks on your television.

Note

- When the Progressive scan mode is selected, the VIDEO and S-VIDEO outputs do not feed any signals.

Connecting the FM and AM(MW/LW) Antennas


If AM reception is poor, connect an outdoor AM antenna(not supplied).
If FM reception is poor, connect an outdoor FM antenna (not supplied).
1
2
3
COAXIAL
FM 75Ω
AM Loop Antenna (supplied)
ANTENNA
AM
COAXIAL
FM 75Ω
Snap the tabs on the loop into the slots of the base to assemble the AM loop antenna.
COAXIAL
FM 75Ω
FM Antenna (supplied)
Cooling fan (See “About Cooling Fan” below.)

FM antenna connection

1. **Connect the FM antenna supplied to the FM 75Ω COAXIAL terminal.**
2. **Slowly move the antenna wire around until you find a location where reception is good, then fasten it to a wall or other rigid surface.**

• If reception is poor, connect an outdoor antenna. Before attaching a 75Ω coaxial cable (with a standard type connector), disconnect the supplied FM antenna.

AM(MW/LW) antenna connection

1. **Connect the AM loop antenna supplied to the AM and ⏚ terminals.**
2. **If reception is poor, connect an outdoor single vinyl-covered wire to the AM terminal. (Keep the AM loop antenna connected).**

(About the cooling fan)

A cooling fan is mounted on the rear panel of the center unit to prevent abnormal temperature inside the center unit, thus assuring normal operation. The cooling fan automatically starts rotating to supply external cool air to the inside of the center unit when the internal temperature exceeds the specified limit.

For safety, observe the following carefully.

• Make sure there is good ventilation around the center unit. Poor ventilation could overheat and cause damage.
• DO NOT block the cooling fan and the ventilation openings or holes. (If they are blocked by a newspaper or cloth, etc., the heat may not be able to escape.)

AUX Connections



Warning

- Always connect the video and audio connection cables to the equivalent colored jack.

CONNECTIONS

To Play External Digital/Analog Equipment

Press **AUX** on the remote control to select DIGITAL IN, AUX1, or AUX2.

Press **Function** on the main unit to select DIGITAL IN, AUX1, or AUX2.

- Each time the button is pressed the mode switches as follows: FM ➞ AM ➞ DVD ➞ DIGITAL IN ➞ AUX 1 ➞ AUX 2.

Controlling a TV with the Remote

You can use the remote control to operate other manufactures' TV.

1 **Turn on the TV.**

2 **Point the DVD's remote at the TV.**

3 **While holding the TV ⏻/I button down, enter the code for your brand.**

- If there is more than one code listed in the table, enter one at a time to determine which code works.

example : For SAMSUNG 1TVs
While holding down the TV ⏻/I button, 0 + 1

4 **If the TV turns off, setup is complete.**

- Now, you can perform the following operations on the TV.

TV ⏻/I	**:** Turn on or off the TV.
VOLUME +/–	**:** Adjust the volume.
TV/VIDEO	**:** Set the input mode (either TV or VIDEO)
CHANNEL +/–	**:** Change the channels.

Option 1

Manufacturer	CODES
Samsung	01,14,15,23
Daewoo	19
Emerson	21
Hitachi	10
JVC	11
LG	06,08,18
Loewe	28
Magnavox	04
Matsushita	24
Mitsubishi	13
Noblex	25
Panasonic	12
Rca	07,29
Sanyo	05,20
Sharp	02,16,22
Sony	03
Toshiba	09
Zenith	17

Option 2

Manufacturer	CODES
Samsung	01~06,32
Akai	12
Flisher	12
Grundig	09,17,21
Hitachi	11,13,14,24
JVC	32
LG	02,30
Mitsubishi	02,16
Mival	29
Nokia	23
Nordmende	13,14,24
Panasonic	08,23~27
Philips	02,20,22
Saba	13,14,22~24
Sanyo	12,16
Schneider	02
Sharp	10,31
Sony	15,16
Telefunken	14,24,28
Thomson	13,14,24,33,34
Toshiba	07,16~19,21

Note

- Manufacturers' codes are subject to change without notice. If they are changed, this remote control cannot operate the equipment.

Connecting your System to the Power Supply

The main lead must be plugged into an appropriate socket.

Before plugging your system into a main socket, you must check the voltage.

Check the position of the voltage selector on the rear of the system (OPTIONAL).
1. Plug the main lead (marked AC Cord on the rear of the system) into an appropriate socket.

2. Press the On/Standby button to switch your DVD Player system on.



Before Using the DVD Player

Your DVD player is capable of playing DVD, VCD, and CD discs.
User instructions may vary depending on the type of disc. Read the instructions carefully before use.

Prepe-rations before use

1 **Turn on the power to your DVD player and TV.**



2 **Select a video mode by pressing the TV/VIDEO button.**

3 **Press the DVD button to select the DVD input function.**

CONNECTIONS

Note

- The "**WAIT**" message that appears on the display for about 4~5 seconds when turning on the power or selecting a DVD function indicates a stabilization period for optimizing the condition of your DVD player. While the message is being displayed, other buttons remain inactive.
- When the power is not turned on, press down the **Stop** (■) button on the main unit for over 5 seconds.
  The product will be initialized to its optimum state.
- As to some operational features such as the Speaker mode, Test tone, Volume, etc. your DVD player will not display their operation on the TV screen.

TV Broadcast System

- **This device is designed to work with the PAL video format.**
- **For normal playback, the video format a DVD disc is recorded in must coincide with your TV's video format.**

TV System Selection

Press the TV System button while in stop mode.

- Each time the TV System button is pressed, "**NTSC**, **PAL**" are selected in this order.
- Different countries use different types of TV broadcast systems, video, audio and channel systems.
  Example : The player cannot playback PAL-encoded DVD with NTSC-TV.

DVD Playback

1

Press the **Open/Close**(⏏) button to open the disc tray.

- The button is located only on the Front Panel of the player (not on the remote).

2

Insert a DVD disc.

- Place a disc gently into the tray with the disc's label facing up.

3

Press the **Open/Close**(⏏) button again to close the disc tray.

- Playback starts automatically.

Pausing Playback

Press the Play/Pause (▶II) button during playback.

- To resume, press the Play/Pause (▶II) button again.

Note

- Depending on the disc, the initial disc information screen may look different from disc to disc.
- When playing a DVD containing MPEG format, video may not be reproduced correctly and you may get picture distortion.

Stopping Playback



Press the Stop (■) button during playback.

- During playback, when the Stop (■)button is pressed, the position is stored in the memory, and ▶■ STOP is shown on the display.
  When the Play/Pause (▶II) button or Return button is pressed subsequently , playback resumes from the position at which it was stopped.
- If the Stop (■) button is pressed a second time, the 'resume play' memory function is canceled, and ■ STOP is shown on the display. When the Play/Pause (▶II)button is pressed, playback starts from the beginning.

Using the On-Screen Display

Press the Display button on the remote.









The On-Screen Display disappears.

OPERATION

What is a Title?

A movie contained in a DVD disc.

What is a Chapter?

Each Title on a DVD disc is divided into several smaller sections called "chapters".

Turning the sound off temporarily?



Press the Mute button during playback.

- This operation may be useful when you need to greet the guests or answer the telephone.

Note If the player is left for more than 3 minutes in pause mode, it will stop.

MP3-CD Playback

This system has a built-in MP3 decoder.
You can play back MP3 tracks (files)recorded on CD-Rs, CD-RWs, and CD-ROMs.

What is MP3? MP3 is an abbreviation of Motion Picture Experts Group (or MPEG) Audio Layer 3. MP3 is simply a file format with a data compression ratio of 1:10 (128 Kbps*). That means,by using MP3 format, one CD-R or CD-RW can contain 10 times as much data volume as a regular CD can.

Starting Playback

- It is recommended you turn on your TV when playing back an MP3-CD.

1

Press the **Open/Close**(⏏) button to load a disc.

2

Press the **Play/Pause**(▶II) button.

- After detecting the disc, playback starts.
- The on-screen bar and the contents recorded on the MP3-CD will be shown on the TV if it is turned on.





1 :	Disc type DVD VCD CD MP3
2 :	Current track (file) and total number of the tracks on the disc • Ex.: 1st track is playing out of 35 tracks recorded.
3 :	Bit rate • Ex.: Bit rate used for recording the loaded disc is 128 Kbps. (See below)
4 :	Repeat mode indicator • Ex.: When repeat mode is turned off.
5 :	Elapsed playing time and the total playing time of the current track
6 :	Sound indication • Indicates sound input level. (Only appears during playback.)

To stop during playback ●●● Press the **Stop** (■) button.

CD-R MP3 DISC

- Only CD-R discs with MP3 files in ISO 9660 or Joliet format can be played.
- The file name of the MP3 file may not be longer than 8 characters and should contain no blank spaces or special characters.
- Use discs recorded with a compression/decompression data rate greater than 128Kbps.
- Only files with the ".mp3" and ".MP3" extensions can be played.
- Only a consecutively written Multisession disc can be played. If there is a blank segment in the Multisession disc, the disc can be played only up to the blank segment.
- If the disc is not closed, it will take longer to begin playback and not all of the recorded files may be played.
- For files encoded in Variable Bit Rate (VBR) format, i.e. files encoded in both low bit rate and high bit rate (e.g., 32Kbps ~ 320Kbps), the sound may skip during playback.

Note Depending on the recording mode, some MP3-CD cannot be played.



Operations Using the On-Screen Display

Turn on your TV when playing back an MP3 disc.

When the loaded MP3 disc is recognized, the following on-screen display appears on the TV screen.
(The contents of this on-screen display vary according to the disc — the way MP3 tracks were recorded on the disc.)

Button	To do
ENTER, ▶II	Start playback or go into a directory.
▲/▼	Select a track or directory.



CD-R/RW playback compatibility

- Your DVD player can also play CD-R and CD-RW discs recorded in digital audio format. When recording your own CD-R or CD-RW discs, make sure that the recording session is properly terminated, or they will not be playable. (Depending on disc properties and recording quality, some CD-R/RWs may not be playable.)
- CD-RW has a lower reflection rate than CD-R media and consequently it will take a longer to read CD-R discs.
- CD-RW discs recorded at high speed tend to be difficult for the DVD player to read. If the recording speed for the CD-RW disc is not predetermined, write it at low speed.

OPERATION



Repeating Playback

On an MP3 disc, Repeat A↔B cannot be used.
You can enjoy only repeat play.

Press the Repeat button.
The indication corresponding to the selected mode appears on the TV screen.

- Each time you press the button, repeat mode changes as follows:



REPEAT:RANDOM
: All tracks recorded on the disc will be played once in random order.
REPEAT:ONE
: Current track will be repeated.
REPEAT:DIR
: Tracks in the current directory will be repeated.
REPEAT:DISC
: All tracks on the disc will be repeated.
REPEAT OFF
: Repeat play is canceled.(Normal play is resumed.)

Forward/Reverse Searching

During playback, you can search quickly through a chapter or track for a specific scene or tune.

High-Speed Playback

DVD VCD CD

Press the ◀◀ and ▶▶ button.

Each time the ◀◀ button is pressed

◀◀ X 2 → ◀◀ X 4 → ◀◀ X 8 → ◀ PLAY

Each time the ▶▶ button is pressed

▶▶ X 2 → ▶▶ X 4 → ▶▶ X 8 → ▶ PLAY

• ◀ playback (reverse playback) is possible on DVDs.

Skipping through a Chapter

DVD VCD CD

Press the ⏮ and ⏭ button.

• Each time the button is pressed during playback, it moves to the next or previous chapter and plays it.



Playing Frame by Frame

DVD VCD

Step

Press the Step button.

• The picture moves forward one frame each time the button is pressed.

Note

No sound is heard during high-speed playback, slow playback, and step motion.

Slow Playback/Checking the Remaining Time

Playing Slowly





DVD VCD

Press the Slow button.

Each time the Slow button is pressed

DVD

I▶SLOW 1/2

I▶SLOW 1/4

▶PLAY

VCD

The slow playback speed changes and the selections (1/2X, 1/4X, 1/8X, 1/16X and normal play) are repeated.

OPERATION

Checking the Remaining Time



DVD VCD CD

Press the Remain button.

- For checking check the total time and the remaining time of a title or chapter being played.

Each time the Remain button is pressed

DVD

TITLE TIME

REMAIN TIME : TITLE

CHAPTER TIME

REMAIN TIME : CHAPTER

VCD CD

TRACK TIME

REMAIN TIME : TRACK

DISC TIME

REMAIN TIME : DISC

Repeat Playback

Repeat playback allows you to repeat a chapter, title, or track.

Playing Repeatedly



DVD VCD CD

Press the Repeat button.

Each time the Repeat button is pressed

DVD

REPEAT : CHAPTER → REPEAT : TITLE → REPEAT OFF

VCD CD

REPEAT : ONE → REPEAT : DISC → REPEAT OFF

Note

- Repeat playback operation is not possible with version 2.0 VCD discs if PBC is turned on. To operate this feature, press the MENU button, and then select "PBC OFF".

A↔B Repeat Playback



DVD VCD CD

1 Press the **Repeat A↔B** button at the beginning (A) of the segment you want to review.

2 Press the **Repeat A↔B** button again at the end (B) of the segment you want to review.

- The segment will begin repeating.

REPEAT : A- → REPEAT : A - B → REPEAT OFF

To return to normal playback

Press the **Repeat A↔B** button again.

Using Disc Menu/Title

To Select the Disc Menu



You can use the menus for the audio language, subtitle language, profile, etc. DVD menu contents differ from disc to disc.

1 Press the **Menu** button during playback.

2 Use the **Up/Down** (▲ / ▼) or **Left/Right**(◄ / ►) button to access the different features.

3 Press the **Enter** button.

- The Menu Screen appears.
- When playing a VCD version 2.0, you can operate it using PBC On/Off function.

- The selected item will play.

Using the Title Menu



For DVDs containing multiple titles, you can view the title of each movie.
Depending on the disc, this function may either not work at all, or may work differently.

To move directly to a title, chapter, or time



1 Press the **Go To** button.

2 Press Number(0~9) button or the **Left/Right** (◄ / ►) button.

- Each time the button is pressed, it repeats as shown below.



- Each time the buttons are pressed the desired scene is located and then played.
- Depending on the disc, the Title function may not work.

OPERATION

Selecting the Audio Language/Subtitle Language

Selecting the Audio Language



Press the Audio button.

- Depending on the number of languages recorded on a DVD disc, a different audio language (ENGLISH, SPANISH, FRENCH, etc.) is selected each time the button is pressed.



Note

- Depending on the disc, DTS or DIGITAL PRO LOGIC can be selected.

Selecting the Subtitle Language



Press the Subtitle button.

- Depending on the number of languages recorded on a DVD disc, a different subtitle language (ENGLISH, SPANISH, FRENCH etc.) is selected each time the button is pressed.
- To make the subtitles disappear, select "OFF".



Note

- If the word ⃠ INVALID appears on the TV screen while buttons are being operated, that operation is not possible with that particular disc.
- Depending on the disc, the audio or subtitle language function may not work.

Zoom/Angle Functions

To enlarge an image



Press the Zoom button.

- Images can be enlarged 2x and 4x.
- During DVD playback, press the **Zoom** button to zoom in 2X/4X/normal, in that order.
- Press ◄ / ► / ▲ / ▼ to move the enlarged portion you want to watch.



Note

- Only 2X zoom operation is possible during VCD playback.

Selecting the desired Screen Angle



Press the Angle button.

- This function only works with discs on which multiple angles have been recorded.
- During playback, press the **Angle** button to select the desired angle: 1/3, 2/3, 3/3, normal, in that order.



OPERATION

Program Playback

Use this function with video and music CDs to play the tracks in a particular order.



To Program Tracks in a particular order

1 Press the **Program** button.

2 Press the **Enter** button then use the Number buttons to select the desired title.

- You can use also just the **Up/Down/Left/Right/Left/Right** (◀/ ▶/ ▲/ ▼) button.

3 Press the **Enter** button, then use the Number buttons to select the desired chapter.

- You can use also just the **Up/Down/Left/Right**(◀/ ▶/ ▲/ ▼) button.







4 Press the **Enter** button.

- The selected track number is programming and the cursor moves to the next number.



5 At this time, you can continue programming if you want to.

- When programming more than 10 tracks, select NEXT↓ and then press the **Enter** button. The program selection screen where you can program up to 10 additional tracks appears.



To Playback the Tracks in the Programmed Order

Press the **Play/Pause** (▶II) button.

To Cancel the Programming

Press either the **Program** button or **Stop** (■) button.

To Change the Program

DVD

1

Press the **Up/Down** (▲/▼) button to select the track number to be changed.

2

Press the **Enter** button to select the title or chapter to be changed.

- The cursor moves to the next number when the **Enter** button is pressed again.

3

Press the **Clear** button and then press the Number buttons.

- You can use also just the **Left/Right** (◀ / ▶) button.

4

Press the **Enter** button.

- The cursor moves to the number below.

5

Repeat steps 1-4 above to change the program.

OPERATION

To delete the entire Program

- Press the **Stop** (■) button twice during playback.
- Press the **Stop** (■) button once when in the Stop mode.
- Press the **Open/Close** (⏏) button on the main unit. The disc tray will open and then close. The program will then be deleted.

When you have entered a wrong number



Press the Clear button.

- When you want to delete a selection during programming, select the track (or chapter, or title) to be deleted and then press the **Clear** button.

Note

You can program or change particular tracks for VCD or CD discs in the same manner.

Sleep/D.R.C Function

To set up Sleep



Press the Sleep button.

- Each time the button is pressed the selection toggles as follows: SLEEP 10 ➔ SLEEP 20 ➔ SLEEP 30 ➔ SLEEP 60 ➔ SLEEP 90 ➔ SLEEP 120 ➔ SLEEP 150 ➔ OFF.

What is the Sleep function?

You can set the sleep time so that the unit powers off automatically after a preset period of time.

To Review Sleep Setting

- Press the Sleep button.
  The remaining time for the selected Sleep time is displayed on the front panel.
- Pressing the button once again changes the Sleep time from the last setting.

Activating Dynamic Range Compression



You can enjoy a powerful sound even at a low volume level by compressing the dynamic range (difference between the maximum and minimum sounds).

From the remote control ONLY:

Press the D.R.C button.

- Each time you press the button,the dynamic range compression mode alternates between on and off. Select "**D.R.C.ON** " while watching the DVD at night. (You can obtain a powerful sound at a low volume.)

Note

- When the **Stop** button is pressed, DRC is switched to Off.

Setting up the Language Features

Using the DVD player's Setup function, you can customize the Menu Language, Subtitle Language, and Disc Menu Language.

To set up the language feature



1

Press the **Setup** button from the stop mode.



2

Press the **Up/Down** (▲/▼) button to select the desired item.



If the **Setup** button is pressed during the language setup, it returns to the stop mode again.

3

Press the **Enter** button or **Right** (▶) button.



4

Press the **Up/Down** (▲/▼) button to select the desired language and then press the **Enter** button.



To End the Language Features Setup



- Press the **Setup** button again.

System Setup

You can use the DVD player's Setup function to select the TV screen ratio, rating limit, or digital output mode.

To Set up the System



DVD

1

From the stop mode, press the **Setup** button.

2

Press the **Left/Right** (◄/ ►) button to select the system.

3

Press the **Up/Down** (▲/▼) button to select the desired item.







4

Press the **Enter** button or Right (►) button.

5

Press the **Up/Down** (▲/▼) button to select the desired sub-item and then press the **Enter** button.





To End the System Setup



- Press the **Setup** button again.

Adjusting the TV Aspect Ratio (Screen Size)

The horizontal to vertical screen size ratio of conventional TVs is 4:3 while that of wide screen and high definition TVs is 16:9. This ratio is called the aspect ratio. When playing DVDs recorded in different screen size, you should adjust the aspect ratio to fit your TV or monitor.

✶ For a standard TV, select either "4:3LB" or "4:3PS" option according to personal preference. Select "16:9" if you have a wide screen TV.



4:3LB (4:3 Letterbox) : Select this to play a 16:9 picture in the letter box mode on a conventional TV.
- Black bars will appear at the top and bottom of the screen.

4:3PS (4:3 Pan&Scan) : Select this to play a 16:9 picture in the pan & scan mode on a conventional TV.
- You can see the central portion of the screen only (with the sides of the 16:9 picture cut off).

16:9 : Select this to view a 16:9 picture in the full-screen mode on your wide screen TV.
- You can enjoy the wide screen aspect.

Note
- However, if a picture is stored on the DVD in the 4:3 ratio, you cannot view it in wide screen.
- Since DVD discs are recorded in various image formats, they will look different depending on the software, the type of TV, and the TV aspect ratio setting.

RATING LEVEL

The Rating Level function works in conjunction with DVDs which have been assigned a rating, to help control the types of DVDs that your family watches.



1. Select RATING LEVEL, then press the Enter button.



2. Use the number(0~9) buttons to input a 4-digit password.
- The player's password is set to "7890" by default.

When the rating level password has been forgotten

While the player is in the stop mode, hold the Stop (■) button down on the main unit for more than 5 seconds.
- "INITIAL" appears on the display and all default settings will return to Factory Preset.
- Press the **Power** button.



3.Use the Up/Down (▲/▼) button to select either RATING LEVEL or NEW PASSWORD, and then press the Enter button.
- There are up to 8 rating levels on a disc.
- If LEVEL 6 is selected, a disc which contains rating LEVEL 7 and above cannot be played.
- If you select NEW PASSWORD, the screen changes and enables you to enter the new password.

SETUP

Speaker Setup

Setting up Speaker Mode and Delay Time



1 Press the SPK Mode button.

2 Press the **Left/Right** (◀ / ▶) button to select the desired item.

- Each time the button is pressed, a different mode selection is displayed on the front panel display as shown below.

Speaker Mode

- F-SP SMALL — Front speaker: Small
- C-SP SMALL — Center speaker: Small
- C-SP NONE — Center speaker: Not Used
- R-SP SMALL — Rear speaker: Small
- R-SP NONE — Rear speaker: Not Used
- SW-SP USE — Subwoofer: Use

Delay Time

- C-DEL 00MS — Center Speaker Delay Time — Setting up Delay Time from 00~05ms
- R-DEL 00MS — Rear Speaker Delay Time — Setting up Delay Time from 00~15ms

• SMALL: When this setting is selected, low frequencies of below 200 Hz are assigned to the subwoofer only.
• USE: Select when using speakers.
• NONE: Select this when no speakers are installed.

Note The display changes depending on the current audio output mode (DSP, PRO LOGIC, 3-STEREO, STEREO, etc.).

Setting up the Speaker Delay Time

When 5.1CH Surround Sound is played, you can enjoy the best sound if the distance between you and each speaker is the same. Since the sounds arrive at the listening position at different times depending on the placement of speakers, you can adjust this difference by adding a delay effect to the sound of the Center Speaker and Surround Speakers.

• Setting CENTER SPEAKER

If the distance of Dc is equal to or longer than the distance of Df in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Df and Dc	Delay Time
50	1.3 ms
100	2.6 ms
150	3.9 ms
200	5.3 ms

• Setting REAR (SURROUND) SPEAKERS

If the distance of Df is equal to the distance of Ds in the figure, set the mode as 0ms. Otherwise, change the setting according to the table.

Distance between Ds and Dc	Delay Time
200	5.3 ms
400	10.6 ms
600	15.9 ms



It is desirable to place all speakers within this circle.

Df: The distance from FRONT SPEAKER
Dc: The distance from CENTER SPEAKER
Ds: The distance from SURROUND SPEAKER

Note Speaker delay time setting is a professional sound volume adjustment method for audio enthusiast. For home use, refer to "Setting up the Ideal Speaker Positions" below to install speakers in appropriate locations.

Ideal Speaker Placement



Front Speakers

Set the front speakers so that their tweeters (high-range) are aligned at about ear level and at a horizontal angle of 45° to the prime listening position.

Center Speaker

Ideally the center speaker should be positioned with its top surface flush with the front speakers. However, you may place the speaker either on top or near the bottom of your TV set.

Rear Speakers

Set the rear speakers further back parallel to the walls, at 60 to 90 centimeters (2 to 3 feet) above prime listening position ear level.
If the space behind the listening position is insufficient (i.e., too close to the wall), place the rear speakers facing each other on either side.

Subwoofer Speaker

Place the subwoofer at any convenient location within the vicinity of the listening position.

To set up Speaker Balance

To set up Speaker Balance

Sound Edit

DVD VCD CD

1 Press the **Sound Edit** button.

2 Use the **Left/Right** (◀ / ▶) button to make adjustment.

- Each time the button is pressed, the selection switches as shown below.

Example: 5.1CH Sound Setup

OFF, range of – 6 ~ 0

Front Speakers: L level, R level



OFF, range of – 6 ~ 0

Rear Speakers: L level, R level



range of – 6 ~ – 00 ~ +6

Center Speaker

range of – 6 ~ – 00 ~ +6

Rear Speakers

range of – 6 ~ – 00 ~ +6

Subwoofer Speaker

Note The display changes depending on the current audio output mode (DSP, PRO LOGIC, 3-STEREO, STEREO, etc.).

Speaker Setting Methods

Test Tone

DVD VCD CD

Press the Test Tone button.

- The test signal will be sent to the Left Front ➞ Center ➞ Right Front ➞ Right Rear ➞ Left Rear ➞ Subwoofer in that order.



To End the Test Tone

Test Tone

- Press the **Test Tone** button again.

Note While in DSP or PRO LOGIC mode, TEST TONE may operate differently for VCDs or CDs.



Creating Realistic Sound Fields

You can use the following surround modes to reproduce a realistic sound field.
• Digital Multichannel Surround —Dolby Digital and DTS Digital Surround
• Dolby Pro Logic Ⅱ

Dolby Digital and DTS Digital Surround

To enjoy surround effectively, all the speakers need to be connected and activated.

Dolby Digital
Used to reproduce multichannel sound tracks of the software encoded with Dolby Digital (DOLBY DIGITAL).

Dolby Digital encoding method (discrete 5.1 channel digital audio format)records and digitally compresses the left front channel,right front channel,center channel,left rear channel,right rear channel,and LFE channel signals (total 6 channels,but LFE channel is counted as 0.1 channel.Therefore, LFE is called the 5.1 channel).
In addition,Dolby Digital enables stereo rear sounds,and sets the cutoff frequency of the rear treble at 20 kHz,compared to 7 kHz for Dolby Pro Logic.These facts result in better sound quality than Dolby Pro Logic.

When the system detects Dolby Digital signals,the DOLBY DIGITAL indicator lights up on the display.

DTS Digital Surround
Used to reproduce multichannel sound tracks of the software encoded with DTS Digital Surround (DIGITAL dts SURROUND).

DTS Digital Surround is another discrete 5.1 channel digital audio format available on CD,LD,and DVD software.
Compared to Dolby Digital,audio compression rate is relatively low.
This fact allows DTS Digital Surround format to add breadth and depth to the reproduced sounds.As a result,DTS Digital Surround features natural,solid and clear sound.

When the system detects DTS Digital Surround signals, the DTS indicator lights up on the display.

Dolby Pro Logic II

- Dolby Pro-Logic II is a new multi-channel playback format developed by Dolby Laboratories using feedback logic steering technology and offering improvements over conventional Dolby Pro Logic circuits.
- Dolby Pro Logic II can be used to decode not only sources recorded in Dolby Surround (DOLBY SURROUND) but also regular stereo sources into five channels (front left, front right, center, surround left and surround right) to achieve surround sound.
- Whereas with conventional Dolby Pro Logic the surround channel playback frequency band was limited, Dolby Pro Logic II offers a wider band range.
  In addition, the surround channels were monaural (the surround left and right channels were the same) with previous Dolby Pro Logic, but with Dolby Pro Logic II they are stereo.

*** Sources recorded in Dolby Surround**
These are sources in which three or more channels of surround have been recorded as two channels of signals using Dolby Surround encoding technology.
Dolby Surround is used for the sound tracks of movies recorded on DVDs, LDs and video cassettes to be played on stereo VCRs, as well as for the stereo broadcast signals of FM radio, TV, satellite broadcasts and cable TV.
Decoding these signals with Dolby Pro Logic makes it possible to achieve multi-channel surround playback.
The signals can also be played on ordinary stereo equipment, in which case they provide normal stereo sound.

Manufactured under license from Dolby Laboratories. "Dolby," "Pro Logic," and the double-D symbol are trademarks of Dolby Laboratories. Confidential Unpublished Works. ©1992–1997 Dolby Laboratories, Inc. All rights reserved.

Manufactured under license from Digital Theater Systems, Inc. US Pat. No. 5,451,942 and other world-wide patents issued and pending. "DTS" and "DTS Digital Surround" are trademarks of Digital Theater Systems, Inc. ©1996 Digital Theater Systems, Inc. All rights reserved.

Dolby Pro Logic II decoder



Dolby Pro Logic II

DVD VCD CD

Dolby Pro Logic II is a new format for playing multichannel audio signals that offers improvements over conventional Dolby Pro Logic. It can be used to decode not only sources recorded in Dolby Surround, but also regular stereo sources into five channels (front left/right, center and surround left/right). In addition, various parameters can be set according to the type of source and the contents, so you can adjust the sound field with greater precision.

1

Press the **Function** button on the front panel to select the desired function.

- Select from FM → AM → DVD → DIGITAL IN → AUX 1 → AUX 2.

2

Press the **Pro Logic II** button.

- Each time the **Pro Logic II** button is pressed.

3

Press the DSP/DPL II **Mode** button.

- Each time the DSP/DPL II **Mode** button is pressed.



Pro Logic II Mode

Select one of the modes (“MUSIC”, “CINEMA”, “PRO LOGIC” or “MATRIX”).

- The Music mode is recommended when listening to CDs or watching DVDs with mostly musical content.
- The Cinema mode is best when watching movies.
- The Pro Logic mode offers the same surround processing as original Pro Logic and is best used when the source contents are not of optimum quality.
- The Matrix mode is useful for when the audio is mono.



Dolby Pro Logic II Effect Function

This function works only in the DPL II M (Dolby Pro Logic II **Music**) Mode.

1 Press the DSP/DPL II **Effect** button.

2 Use the **Left/Right** (◀ / ▶) button to make adjustments.

• Each time the DSP/DPL II **Effect** button is pressed.


PANORAMA 1
PANORAMA 0
Select “0” or “1”
C-WIDTH 4
C-WIDTH 6
The control can be set in 8 steps from 0 to 7.
DIM 1
DIM 3
The control can be set in 7 steps from 0 to 6.

- **Panorama Mode**
  This mode extends the front stereo image to include the surround speakers for an exciting “wraparound” effect with side wall imaging.
- **Center Width Control**
  This control adjusts the center image so it may be heard only from the center speaker; only from the left/right speakers as a phantom image; or from all three front speakers to varying degrees.
- **Dimension Control**
  This control gradually adjusts the soundfield either towards the front or towards the rear.

Note

• When playing a DVD encoded in two or more channels, DOLBY PRO LOGIC II mode cannot be selected.

SETUP

DSP(Digital Signal Processor) Modes

DSP modes have been designed to simulate different acoustic environments.
The sound heard in a hall, theater, pavilion, dance club, or live club consists of direct and indirect sound —early reflections and reflections from behind.
Direct sounds reach the listener directly without any reflection.
Indirect sounds are delayed by the distance of the ceiling and walls.
These indirect sounds are an important element of the acoustic surround effect.



Press the DSP/DPLⅡ Mode button.

- This function works only in the STEREO Mode.
- The following DSP modes are provided with this unit:

HALL Provides a clear vocal and simulates the feeling of a concert hall.

THEATER Simulates the feeling of a theater.

PAVILION Simulates the spacious feeling of a pavilion with a high ceiling.

DANCE CLUB Simulates the sound of a dance club with a throbbing bass beat.

LIVE CLUB Simulates the feeling of a live music club with a low ceiling.

- These DSP modes can be used to add acoustic surround effects while reproducing stereo analog or linear PCM digital signals.
- When one of the DSP modes is selected,the DSP indicator lights up on the display.

DSP modes available according to the input signal format

O : Possible, X : Not possible

Surround		Multichannel Surround	DSP					(canceled)
			HALL	THEATER	PAVILION	DANCE CLUB	LIVE CLUB	STEREO
Input Signal format	Analog	X	O	O	O	O	O	O
	Linear PCM	X	O	O	O	O	O	O
	Dolby Digital	O	X	X	X	X	X	X
	DTS	O	X	X	X	X	X	X

To increase Effect level



To increase Effect level

Press the DSP/DPL II **Effect** button.

- The effect level can be set in steps from 1 to 4 EFFECT1 → EFFECT2 → EFFECT3 → OFF(DEFAULT).
  Each time the button is pressed the selection moves to the next effect.
- The higher the number, the stronger the DSP surround effect will be.

What is a Effect?

This sets the strength of the DSP mode.

Note • This function works only in the DSP Mode.

Adjusting DSP Sound Parameters

You can fine-adjust DSP modes more minutely by changing three parameters—room, liveness, and reverberation.



1

Press the DSP/DPL II **Mode** button.

2

Press the **Sound Edit** button.

- Each time you press the button, the indication on the display changes as follows:

00 F 00 → 00 R 00 → REAR → SW → ROOM → LIVE → REVERB → Normal indication (canceled) → 00 F 00

ROOM : To adjust the resonance based on the room size. The larger this value is, the more effective the resonance is (from 04 to 16 by 2 steps).

LIVE (Liveness) : To adjust the liveness. The larger this value is, the more liveness is obtained (from 04 to 16 by 2 steps).

REVERB (Reverberation) : To adjust the reverberation time of the sound (from 0.0 msec to 1.6 msec by 0.2 msec steps).

3

Press the **Left/Right** (◄ / ►) button to adjust the DSP sound parameter.

Note • This function works only in the DSP Mode.

Listening to the Radio

You can listen to the chosen band (FM, MW broadcast stations) by using either the automatic tuning or manual tuning operation.

Remote Control Unit

1 Press the **Tuner(Band)** button.

- The selection toggles back and forth between "FM" "MW" each time the **Tuner(Band)** button is pressed.

2 Select a broadcast station.

Auto Station 1	When the ⏮ ⏭ button is pressed, a preset broadcast station is selected.
Auto Station 2	Hold in the ◀◀ ▶▶ button. Automatic searching begins, and then stops when a station is tuned in.
Manual Station	Press the ◀◀ ▶▶ button to tune to the chosen station. The frequency changes incrementally in either direction each time the corresponding button is pressed.

Main Unit

1 Press the **Function** button to select the desired band (FM, MW).

2 Select a broadcast station.

Auto Station 1	Press the **Stop** (■) button to select the PRESET mode. Then press the ⏮ ⏭ button to select a station stored in the preset
Auto Station 2	Press the **Stop** (■) button to select the MANUAL mode on the front panel. Then hold in the ⏮ ⏭ button to make the unit begin automaticall searching for broadcast stations.
Manual Station	Press the **Stop** (■) button to select the MANUAL mode front panel. Press the ⏮ ⏭ button to tune to the desired station. The frequency changes incrementally in either direction each time the corresponding button is pressed.

To Listen in Mono/Stereo

Press the MO/ST button. (only FM)

- The selection toggles back and forth between “STEREO” and “MONO” each time the **MO/ST** button is pressed.
- In a poor reception areas, select Mono mode for a clear, interference-free broadcast.

Presetting stations

You can store up to:

- 15 FM stations
- 15 MW stations

- **FM** ..... Frequency Modulation
- **AM(MW)** ..... Medium Wave

Example: Presetting FM 89.1 in the memory

1

Press the **Tuner(Band)** button and select the FM band.

2

Select the MANUAL by pressing the **Stop** (■) button on the main unit.

3

Use the ◀◀ and ▶▶ button to tune into 89.1

- The selection toggles back and forth between " FM → AM(MW) " each time the **Tuner(Band)** button is pressed.

4

Press the **Program** button on the remote control, FM1 will flash. If you want to save 89.1 to FM1, press Program again.

5

If you want to save 89.1 to another preset location(FM2~FM15), press ⏮ or ⏭, then press **Program** to save it to that location.

6

To preset other stations, follow steps 1~5 again.

To tune in a preset station

See the previous page.

Troubleshooting

Problem	Check
The disc tray does not open.	• Is the disc installed with the label side facing up? • Is the power cord plugged securely into the power outlet? • Turn off the power to the unit by pressing the **Power** (⏻/I) button and turn it back on.
Disc does not play.	• Check the region number of the DVD. • DVD discs purchased abroad may not be playable. • This player cannot play CD-ROMs, DVD-ROMs, etc. • Check the rating level of the DVD.
Playback does not start immediately when the Play/Pause button is pressed.	• Check whether the disc has any scratch marks or is deformed?
No sound is produced.	• No sound is heard during high-speed playback, slow playback, and step motion playback modes. • Are the speakers properly connected? Is the speaker Setup correctly customized? • Is the disc severely damaged? The disc may be dirty. Wipe off fingerprints or dirt.
Sound can be heard only from a few speakers and not all six.	• When listening to a CD or radio, sound is output to the front speakers only (L/R). Select the “PRO LOGIC” option by pressing the Pro Logic button on the remote control unit to use all six speakers. • Check whether your DVD disc is 5.1 CH compatible.
Picture does not appear; sound is not produced; the disc tray opens 2-5 seconds later.	• Was the player moved suddenly from a cold pace to a warm one? When condensation forms inside the player, remove the disc and let the player stand for 1 or 2 hours with the power on. (You can use the player after the condensation disappears.)
Sound quality is irregular.	• Are the speaker cables loose? • Is there any dirt or debris at the end of the speaker connector?
Dolby Digital 5.1 Channel Surround Sound is not being reproduced.	• Does the disc being played show the “Dolby Digital 5.1CH” mark ? 5.1-channel sound is reproduced only if the disc is recorded with 5.1 channel sound. • Is the DVD player connected to the proper speakers?

Problem	Check
• The disc revolves but no picture appears. **• Picture shows interference and quality is poor.**	• Is the TV power turned on? • Are the video cables properly connected? • Is it the player in PAUSE mode? • Is your TV's video format (NTSC/PAL) set correctly? Press the NTSC/PAL button once again to change the current selection. • Is there any dirt on the disc, or is the disc damaged? • It may not be possible to play some DVD discs due to poor manufacture. • When a dark scene changes to a bright scene during playback, the screen may flicker vertically. Some disturbance is normal.
Remote control unit does not operate.	• Is the remote control being used within the appropriate distance and angle of operation for the unit? • Are there any obstacles between the remote control unit and the remote control sensor? • Are the batteries dead? Is it time to replace the batteries with new ones?
Audio or subtitle language does not operate.	• The audio or subtitle language features does not operate with DVDs that do not include multiple audio or subtitle languages.
The Menu button is pressed but the Menu screen does not appear.	• Is the remote control being used within the appropriate distance and angle of operation for the unit? • Are the batteries dead? • Does tje disc have a Menu?
The screen ratio cannot be changed.	• You can play 16:9 wide DVDs in 16:9 WIDE mode, 4:3 LETTER BOX mode or 4:3 PAN-SCAN mode; but 4:3 encoded DVDs only show in 4:3 ratio. Refer to the DVD disc jacket and then select the appropriate function.
The desired radio station cannot be tuned in.	• Is the antenna installed properly? • When the antenna's input signal is weak, install an external FM antenna in an area with good reception quality.
The system is malfunctioning (the system does not work or no sound).	• While the player is in the stop mode, hold the Stop (■) button down on the main unit for over 5 seconds."INITIAL" appears on the display and all settings will return to the Factory Preset condition. **The RESET function erases all settings; do not use this function unless necessary.**

Cautions on Handling and Storing Discs

Small scratches on the disc may reduce sound and picture quality or cause breaks in playback. Be especially careful not to scratch discs when handling them.

Handling and Storing Discs

When you get fingerprints or dirt on the disc, clean it with a mild detergent diluted in water and wipe with a soft cloth.

- When cleaning, wipe gently from the inside to the outside of the disc.

Note

Condensation may form if warm air comes into contact with cold parts inside the player. When condensation forms inside the player, the player may not operate correctly. If this occurs, remove the disc and let the player stand for 1 or 2 hours with the power on.

Disc Storage

Do not keep in direct sunlight



Keep in a cool ventilated area



Keep in a clean Protection jacket. Store vertically.



Warning

- Do not allow the discs to become contaminated with dirt.
- Do not load cracked discs or discs that are scratched.



Disc Type and Protection

Usable Discs

Disc Types	Marks	Recording Types	Disc Size	Max. Playing Time
DVD	DVD VIDEO	Audio + Video	12cm	Approx. 240 min. (Single-sided)
				Approx. 480 min. (Double-sided)
			8cm	Approx. 80 min. (Single-sided)
				Approx. 160 min. (Double-sided)
VIDEO-CD	COMPACT disc DIGITAL VIDEO	Audio + Video	12cm	74 min.
			8cm	20 min.
AUDIO-CD	COMPACT disc DIGITAL AUDIO	Audio	12cm	74 min.
			8cm	20 min.

DOLBY DIGITAL	DIGITAL dts SURROUND	DIGITAL SOUND	STEREO	NTSC	MP3 DIGITAL DISC PLAYBACK
Dolby Digital disc	DTS Disc	Digital Audio disc	Stereo disc	NTSC broadcast system in USA, Canada, Japan, South Korea, etc..	MP3 disc

Specification

GENERAL	Power Consumption	120W		
	Weight	6.6Kg		
	Dimensions (W x H x D)	360mm x 76mm x 365mm		
	Operating Temperature Range	+5°C~+35°C		
	Operating Humidity Range	10%~75%		
FM TUNER	Usable Sensitivity	10dB		
	S/N Ratio	60dB		
	Distortion	0.5%		
AM TUNER	Usable Sensitivity	54dB		
	S/N Ratio	40dB		
	Distortion	2%		
VIDEO OUTPUT	Composite Video	1.0Vp-p(75Ω load)		
	Component Video	Y : 1.0Vp-p(75Ω load)		
		Pr : 0.7Vp-p(75Ω load)		
		Pb : 0.7Vp-p(75Ω load)		
	S-VIDEO	Luminance Signal: 1.0Vp-p(75Ω load)		
		Color Signal: 0.286Vp-p(75Ω load)		
AMPLIFIER	Front speaker output	40W x 2(6Ω), Distortion 10%		
	Center speaker output	40W(6Ω), Distortion 10%		
	Rear speaker output	40W x 2(6Ω), Distortion 10%		
	Subwoofer speaker output	70W(3Ω), Distortion 10%		
	Frequency range	20Hz~25KHz		
	S/N Ratio	75dB		
	Channel separation	50dB		
	Input sensitivity	(AUX)500mV		
SPEAKER	Speaker system	5.1ch speaker system		
		Front/Center/Rear speaker		Subwoofer speaker
	Impedance	6Ω x 5		3Ω
	Frequency range	100Hz~18KHz		40Hz~200Hz
	Output sound pressure level	87dB/W/M		86dB/W/M
	Rated input	40W		70W
	Maximum input	80W		140W
	Dimensions (W x H x D)	Front/Rear	120㎜ x 186㎜ x 130㎜	210㎜ x 367㎜ x 360㎜
		Center	300㎜ x 139㎜ x 121㎜	
	Weights	Front/Rear	1.1Kg	7.1Kg
		Center	1.2Kg	

Reference

Note on Terminology

ANGLE	Recorded onto some DVD discs are scenes which have been simultaneously shot from a number of different angles (the same scene is shot from the front, from the left , from the right , etc.). With such discs, the Angle button can be used to change the angle of view for specific scenes.
CHAPTER NUMBER	These numbers are recorded on DVD discs. A Title is subdivided into many sections, each of which is numbered, and specific parts of the video can be searched quickly using these numbers.
DVD	A high-density optical disc on which high-quality pictures and sound have been recorded by means of digital signals. Incorporating a new video compression technology (MPEG-2) and high-density recording technology, a DVD disc comprises two 0.6 mm thick discs bonded together.
PCM	An acronym for Pulse Code Modulation - another name for digital audio.
PBC (PLAYBACK CONTROL)	This is recorded on a video CD (version 2.0). Selected scenes or information can be chosen from the menu displayed on the TV monitor.
REGION NUMBER	Both the DVD player and DVD discs are encoded with a region number. If the region number on the DVD disc does not correspond to the region number of the DVD player, the player cannot play the disc.
SUBTITLES	Translated appearing at the bottom of the screen. A DVD disc can contain up to 32 subtitle languages.
TITLE NUMBER	These numbers are recorded on DVD discs. When a disc contains two or more movies, these movies are numbered as Title 1, Title 2, etc.
TRACK NUMBER	These numbers are assigned to the tracks which are recorded on video and audio CDs. They enable specific tracks to be located quickly.
VIDEO CD	Contains recordings of pictures and sound whose quality is roughly comparable to that of video tape. This player also supports video CDs with playback control (version 2.0).
DIGITAL dts SURROUND	You can enjoy 5.1 (or 6) channels of high fidelity digital sound from various digital input sources such as laser discs, DVD, CD etc. DTS provides a realistic, clear surround sound that has not previously been available from conventional surround sound.
DOLBY DIGITAL	5.1 (or 6) Channel Digital Surround sound reproduced from DVDs and LDs recorded as a digital signals (with DOLBY DIGITAL disc marking). With better sound quality, dynamic range, and directionality than the traditional Dolby surround technology, you can enjoy the dynamic realistic sound.
DOLBY DIGITAL PRO LOGIC II	A 4 channel analog sound reproduced from a program source such as a videotape or LD with the DOLBY DIGITAL PRO LOGIC II mark. You can enjoy a more realistic, robust sound unavailable from regular stereo sources.

THIS APPLIANCE IS MANUFACTURED BY:

SAMSUNG ELECTRONICS

AH68-01141J